





Origin

Moves the database origin to a new location with advanced object snapping capabilities. For example, center between object, center of bounding box objects, etc. Useful for centering objects about the origin in the symbol editor.

Features:

- Display the origin.
- Zoom display to center origin.



Help

